

#3238-62 VW® Baja Body for TRAXXAS® SLASH®

For application of this body it is necessary to remove the stock side mounts from your chassis. You have the option of removing the rear bumper to clear the engine detail or cut holes in it for the bumper to pass through.

Tip: Due to the tight tolerances of the Baja body it is recommended to use protective tape, Velcro, or decal strips to protect the paint on your finished body from rubbing on the chassis.. You can do this by attaching it to the body or directly to the sides of the chassis.

